


RT-2400/5100/5100S Accessories Guidelines



- ① Floor Mount
- ② Wall Mount
- ③ 2*110mm Series/Parallel Cable Between Batteries
- ④ 1*280mm Communication Cable Between Batteries
- ⑤ 2*1500mm Power Cable Between Battery and Inverter
- ⑥ 1*1500mm Communication Cable Between Battery and Inverter
- ⑦ 1*350mm Ground Wire Between Batteries